





ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2



Secure the Light Bulb (H) / E14 into the lamp holder (I).

To prevent the risk of fire, do not use bulb with wattage greater than 5W CFL, 7W LED & 25W Regular Bulb.

* IF THE EXTERNAL FLEXIBLE CABLE OR CORD OF THIS WALL LAMP NEED TO BE CHANGED IT SHOULD ONLY BE REPLACED BY A QUALIFIED ELECTRICIAN